

Item	Component
1	Body & Casing
2	Cap
3	Guide
4	Nozzle
5	Screw
6	Disc
7	Seat Holder
8	Down Spring Plate
9	Up Spring Plate
10	Spindle
11	Spring
12	Adjusting Screw
13	Locking Nut
14	O-Ring
15	Outlet Connector
16	Nozzle Connector
17	Flanges
18	Screw
19	Ball
20	Hard Seat Disc
21	Hood

Note:

Items 6,7,14 are used just for soft seat types. Item 20,21 just for hard seat type.

Kiatork can upgrade materials without notice. Every part can be replaced by other material acc. to customer specification.